WARRANTY COVERAGE

Dayton Audio products are warranted to be free of all defects in material and workmanship for 5 YEARS from the date of purchase from an authorized Dayton Audio dealer. This warranty and all rights provided are limited to the original owner and are non-transfer able. Dayton Audio's responsibility is limited to replacement or repair as set forth in this warranty statement.

Should a product require warranty service during this period, Dayton Audio will repair or replace without charge, any part or product proving defective in material or workmanship. All warranty repairs and service must be performed by an authorized Dayton Audio technician or service facility. The use of non-authorized repair services renders this warranty null and void, and any charges relating to non-authorized repair are the responsibility of the product owner.

All expenses related to replacing or repairing a defective part or product under this warranty shall be assumed by Dayton Audio. Dayton Audio reserves the right to replace defective product with a new or factory reconditioned unit.

WARRANTY EXCLUSIONS

This warranty does not cover product failure or damage resulting from misuse, abuse, neglect, accidents, alterations, standard environmental deterioration, natural disasters, or improper use and/or installation.
This warranty does not cover cosmetic damage due to misuse or neglect. This includes paint damage, scratches, cracks or other superficial marks related to improper use.

3. Failures arising from attempted servicing of a non-authorized Dayton Audio repair facility or technician are excluded from this warranty.

LIMITATION OF DAMAGES

In no event shall Dayton Audio be liable for consequential damages for breach of this warranty including installation charges, exces sive shipping expenses, property loss or other incidental loss. Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to the buyer.

HOW TO OBTAIN WARRANTY SERVICE

To obtain services under this warranty, the buyer shall contact Dayton Audio's authorized service provider, Parts Express, at 1-800-338-0531 x 780 to obtain a return authorization number (RA#).

The buyer must carefully pack the warranted product along with a copy of the original purchase receipt, the return authorization number (RA#), and a description to the repair facility listed below. Shipping for warranty service is the responsibility of the buyer. Parts Express Attn: Dayton Audio Warranty Repairs RA# (please write your RA# here)

705 Pleasant Valley Drive Springboro, Ohio 45066

NOTICE TO BUYER

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.




daytonaudio.com tel + 937.743.8248 info@daytonaudio.com 705 Pleasant Valley Dr. Springboro, OH 45066 USA





41" LCR SPEAKER BAR

Model: BS41 User Manual



Thank you for purchasing the Dayton Audio [®] BS41 LCR (Left, Center, Right) Speaker Bar. This small-but-mighty speaker bar combines left, center and right channel speakers into a single convenient mountable bar that can be positioned above or below a wall mounted flat panel display or sit free-standing. When combined with a pair of Dayton Audio SAT-BK satellite speakers and a powered sub, like the Dayton Audio SUB-800, you'll have created a big sound, compact-sized surround sound experience that will impress family and friends.

Key Features


The BS41 uses long excursion 4["] woofers with long-lasting butyl surrounds for wide dynamic range and exceptional bass. Three mylar dome tweeters provide smooth and extended high frequency response. Easy installation. Packed with a pair of rubber feet for table top mounting.

Specifications:

- Three 4" woofers with butyl rubber surrounds
- Three 5/8" mylar dome tweeters
- Sub Crossover setting: 80 Hz
- Optional Receiver Setting: No sub (if no sub used)
- Power handling: 100 watts RMS
- Impedance: 8 ohms
- Frequency response: 50 22,000 Hz
- SPL: 87 dB 1W/1m
- Dimensions: 5" H x 41" W x 3.8" D
- Weight: 17 lbs.

Receiver

Typical wiring of the BS41 LCR speaker bar



Tabletop mounting of BS41 LCR speaker bar




Optional wall mounting of BS41 LCR speaker bar using bracket mounting system (available separately)

Step 1: Attach small bracket by pre-drilling pilot hole positions as shown using supplied screws.

Rear of BS41



Step 2: Identify mounting location and attach wall bracket to the wall using supplied drywall screws. Do not use nails. Attach one end first then pivot until bubble is level. Mark holes and install remaining screws. When using the supplied "Wall Dog" screws it is not necessary to locate a wall stud.



- Step 4: Attach speaker wires as shown in Figure A.
- **Step 5:** Remove bubble level and hang BS41 on wall bracket. BS41 can be moved side-to-side for precise positioning.