




Sound Exciters Installation Instructions

1. Connect the Sound Exciters to the amplifier with the supplied wire
2. Turn the amplifier on and set the volume to a reasonable level
3. Press the Sound Exciter against the intended surface
4. Move the Sound Exciter across the surface until the ideal tone is achieved
5. Peel the backing from the adhesive pads and permanently place the Sound Exciter



NOTE: Before permanently attaching the Sound Exciters, test the placement for optimal sound reproduction.

Specifications:

- Ideal for use with 10~50 Watt Amplifiers
- Wide Frequency Range
- 8 Ohm Impedance
- 6 Watt Power Capacity